

# Play

SITS



# Play

## UPHOLSTERY



fabric



leather

## COMFORTS




standard


## COVERS




fixed




pop




footstool 52x36




tune




tune without buttons



solo




funk




swing


## extra dimensions




depth of seat  
pop




depth of seat  
tune



depth of seat  
solo




depth of seat  
funk




depth of seat  
swing

## legs



no. 180  
wood



no. 184  
metal painted  
black or grey